



Serial port to USB connection

POWER IN, 9V

MAX232

16f877

Sony Ericsson T610

GND

TX

RX

Serial port connection when:
* pic <-> pc
* gsm <-> pc





